



Product Usage

Developer Concentrate for Positve Analoge Plates - ready to use

universal for all popular positive working PS plates

Characteristics

- Highly concentrated (1 part PS Developer + 5 parts water) cost efficient
- · Good buffer capacity in the plate processor long lasting
- Low replenishing rate with Replenishers cost efficient.
- No or very low residues in the processor tank
- Universal in use for all popular positive working plates

Application

Dilute 1 part PS Developer Concentrate with 5 parts of water and mix well.

processor adjustments:

Temperature: 22°C-26°C, start with 24°C

Processor speed: 20-40 seconds, start with 30 seconds

Replenishing rate: 15-40ml/m2, start with 20ml/m2

Packaging

5/20 Litre