



# VIVID Delete PS

Minus Correction/Deletion of Positive-Offset Plates

## Characteristics

---

1. Easy to spread paste:very precise deletion possible
2. Performs thixotrope:NO "Bleeding" effect
3. Corrects gentle:does not attack the oxide surface of the plate
4. Low odour

For all popular Positive Plates .

## Application

---

Apply with a brush, let penetrate ca. 10 – 15 seconds, then remove with a wet sponge.

By shaking the VIVID Delete PS the viscosity can be reduce to the desired level. After some time the former pasty form is coming back again.

For difficult to correct positive plate the more aggressive VIVID Delete PS is recommended.

## Packaging

---

100 ml Bottle

250 ml Bottle