



VIVID Delete CTP

Correction/Deletion of CTP Plates

Characteristics

- Easy to spread paste:very precise deletion possible
- Performs thixotrope:NO "Bleeding" effect
- Corrects gentle:does not attack the oxide surface of the plate
- Low odour

For all popular CTP Plates .

Application

Apply with a brush, let penetrate ca. 10 – 15 seconds, then remove with a wet sponge.

By shaking the VIVID Delete CTP the viscosity can be reduce to the desired level. After some time the former pasty form is coming back again.

For difficult to correct positive plate the more aggressive VIVID Delete CTP is recommended.

Packaging

100 ml Bottle

250 ml Bottle

Vivid Manufacturing Co. Pvt. Ltd., 14/7, Site-IV, Industrial Area, Sahibabad-201010,U.P.

E-mail : info@vividchem.com WebSite: www.vividchem.com